

## BMX bike: assembly instructions

Information on how to assemble your Bergsteiger bike can be found in the scope of delivery included main manual. Please be sure to familiarize yourself with it.

In particular, improper assembly of the pedals (ignoring the pedal markings) can lead to damage.

You can find our assembly video at: [www.bergsteiger-fahrrad.de/support](http://www.bergsteiger-fahrrad.de/support)

### Stem & Rotor System

Insert the handlebars and mount the stem cap. Important: Cross-tighten the screws. Pay particular attention not to damage any thread of the stem. Please screw the first turn by hand and never use a cordless screwdriver or similar.



After attaching the handlebars, screw the Bowden cables into the first rotor plate. Then the end of the Bowden cable can be hooked into the second rotor plate. You can pull the second rotor plate up a little. The brake can be adjusted using the adjusting screws on the brake handle and rotor plate.

### Inserting the front wheel & mounting the brake

If your bike is equipped with a V-brake, you can unhook the silver guide tube from the brake arm, insert the front wheel, squeeze the brake arms and (with a little force) hook the guide tube back in place.



If your bike is equipped with a U-brake, you can loosen the fastening screw of the Bowden cable on the brake arm before mounting the front wheel. With the front wheel in place, squeeze the brake arms together until the brake shoes just clear the rim (about a dime should fit between them) and retighten the bolt.



*bergsteiger*

## Pegs

Depending on the model, BMX pegs are included in the scope of delivery. These are screwed onto the axle ends. The holes in the pegs can be used to tighten them (e.g. with a screwdriver).



We wish you a good ride and a lot of fun with your Bergsteiger bike!